


Lithium battery air pump

Please read the following instructions and warnings before use.

Please fully charge the battery at least once every 6 months to ensure normal use of the product.



1. Precautions

- * Air pumps are used to inflate and deflate items, such as air beds and air cushions.
- * Please keep the air pump out of the reach of children.
- * Do not block the vent holes of the air pump and keep it ventilated.
- * In order to inflate quickly and shorten the working time of the motor, the appropriate nozzle should be selected according to the valve size of the inflatable product.

2. Warning

- * To reduce the risk of using the air pump, please contact a qualified electrician immediately to repair or replace damaged wires.
- * When inflating, carefully follow the instructions on the inflatable item. Do not exceed the recommended pressure, otherwise serious injury may result.
- * Do not leave the pump unattended while it is in use.
- * Do not use the air pump in lake temperature environments.
- * When using the system, never allow sand, small stones, etc. to be sucked into the inflation and deflation ports.
- * When the air system is working, do not look inside and do not point the inflation and exhaust ports towards your eyes.

3. Battery Charging

- * Make sure the USB interface voltage is 5V when charging
- * General USB cable; you can also use adapters with USB interfaces, such as mobile phone adapters, power sockets, computer adapters, etc.
- * The display light is on when charging, one light indicates 25% charging, two lights indicate 50%, three lights indicate 75%, and four lights indicate 100%.

4. Product Inflation

- * Directly use the air pump with a fully charged battery.
- * Connect the nozzle to the inflation port, then lean the pump against the valve of the inflatable item, turn on the inflation switch/turn off the stop switch. (Double-click to start/turn off to start)
- * The valve of the inflatable item should not be blocked. Otherwise, it will overheat and damage the air pump.
- * For large items, such as inflatable boats and extra-large air cushions, the pump should be directly matched with the valve of the inflatable item for quick inflation. Use an appropriate nozzle for small valves, such as single-caliber cushions, etc.

5. Deflate the product

- * Open the valve of the inflatable item. Connect the nozzle to the deflation port, insert the valve, and turn on the deflation switch/close the stop switch. *The valve of the inflatable item should not be blocked. Otherwise, it will overheat and damage the air pump. For small valves of inflatable items.
- * You can use your fingers to pinch the baffle of the valve to let the air escape.
- * If you want to inflate quickly with a butterfly valve, unscrew the safety bolt and inflate directly with the pump.



Usage Matters



**This product is in power-off protection state when it leaves the factory
It needs to be charged and unlocked before use.**

Do not turn on the machine and run it idle for more than 5 minutes

The machine will be damaged due to overheating of the motor.

Press and hold for 5 seconds to charge and unlock.

Double-click to turn on and single-click to turn off