

XG0133K03-A


Product accessories and quantity
















Eccentric piece installation steps



Overall partial installation



1. Product accessories and quantity (it is recommended to put more spare screws)

			
4*35 self-tapping screws	4*14 handle screw	small nails	Metal feet
B3*9 (includes 1 spare)	B14*3 (includes 1 spare)	K20*26 (includes 2 spares)	M24*4
			
Eccentric rod + eccentric wheel	Built-in door catch	Medium black (gold) color rectangular handle	Single hole door iron sheet
D0*5 (includes 1 spare)	L18*2	J47(gold)/J49(black)*1	L19*2
			
Iron partition pin	3.5*12 self-tapping screws	door hinge	
K0*16 (includes 2 spares)	A1*24 (includes 2 spares)	K2*2	
			
breathable hole		screwdriver	
K11*3		1	

Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

5. If there are extra screw accessories, they are spare screws provided by the manufacturer!

2. Installation steps of eccentric parts



Screw the eccentric rod to the board



Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole



Rotate 180° clockwise to lock
the board left and right



6

3. Start the installation: overall and partial installation

<1>



⑤ Bottom plate




① Left side panel



③ Right side panel




Circle the small hole on No. 5 plate 1



Circle the small hole on board No. 1.3 and place it at the bottom B3


4*35 self-tapping screws
B3*4

	OR	
Metal feet		3.5*12 self-tapping screws
M24*4		A1*16



Use A1 to fix M24 everywhere on the pinhole marks on both sides of the No. 5 board.

Install L18 on board No. 4, with the magnetic side of L18 facing sideways.



	
Built-in door catch	Eccentric rod
L18*2	D0*4



④ Cover

Screw the D0 (eccentric rod) into the non-penetrating hole on No. 4 board


Eccentric wheel
D0*4

Insert D0 (eccentric wheel)

Tighten clockwise to lock the board



L18 on board No. 4 is up and facing forward.



Whole flip

Insert K11 into the round hole




breathable hole	small nails
K11*3	K20*24

② Large back panel (two pieces in total)

① Small back panel

Knock in the K20 with a tool hammer

(You need to bring your own tool hammer)



<5> Overall alignment



Plug KO into boards 1 and 3, and there are two holes on the inside, the upper and lower holes. The purpose is to make the shelf adjustable (the shelf can be placed diagonally to accommodate larger shoes)

<6>




⑥ Large movable floor

Place plate 6 on the KO



Insert KO into the hole in the door panel



(8) Left door panel (9) door panels

Medium black (gold) color rectangular handle	Single hole door iron absorber	3.5*12 self-tapping screws	4*14 handle screw
J47(gold)/J49(black)*1	L19*2	A1*6	B14*2

1. Align the KO above the door panel

At the eye mark on the door panel, insert A1 into the small hole under the L19/4 plate.



Completed picture



The installation is complete: