







# SOCE010-90/100CM

Please be sure to use a manual screwdriver and refrain from using an electric drill.



1. Product accessories and quantity (it is recommended to put more spare screws)

			
4*40 self-tapping screws	<b>small nails</b>	Eccentric wheel + eccentric rod	3.5*12 self-tapping screws
<b>B4*41</b> (includes 2 spares)	<b>K20*44</b> (Contains 2 spares)	<b>D0*5</b> (includes 1 spare)	<b>A1*19</b> (Contains 2 spares)
			
6*25 flat head screws	White rebounder (single head)	Iron partition pin	breathable hole
<b>E4*6</b> (includes 1 spare)	<b>S33*1</b>	<b>K0*15</b> (includes 1 spare)	<b>K11*3</b>
			
Single hole door iron absorber	door hinge		
<b>L19*3</b>	<b>K2*3</b>		
			
White rebounder (double-headed)	screwdriver		
<b>S32*1</b>	<b>1</b>		

## Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

5. If there are extra screw accessories, they are spare screws provided by the manufacturer!

## 2. Installation steps of eccentric parts



Screw the eccentric rod to the board



Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole



Rotate 180° clockwise to lock  
the board left and right




### 3. Start the installation: drawer partial installation


<1>

Non-penetrating hole on plate


19. Screw in DO (eccentric rod)



19 Drawer panel



20 Drawer left side panel




21 Drawer right side panel

Insert DO (eccentric wheel)



<2>




23 Drawer bottom



<3>



22 Drawer back panel






The drawer part is installed

#### 4. Overall partial installation


<1>

Place S33 on the pinhole of No. 10 board and fix it with A2, with the magnetic side facing out.



⑩ Door upper panel

Place S32 on the pinhole of No. 7 board and fix it with A2, with the magnetic side facing out.



⑦ Roof plate

Non-penetrating hole on No. 7 plate

screws in the DO (eccentric rod)

White rebounder (double-headed)	White rebounder (single head)	3.5*12 self-tapping screws	Eccentric rod
S32*1	S33*1	A1*8	D0*2



① left side panel



③ middle riser



4*40 self-tapping screws
B4*2

Eccentric wheel
D0*2



⑦ Roof plate

Circle the non-penetrating holes on plates 1 and 3 and face each other.




<2>



⑧ Drawer lower board


4*40 self-tapping screws
B4*4




<3>



⑨ Baffle


4*40 self-tapping screws
B4*2




<6>



11 Door lower shelf


4*40 self-tapping screws
<b>B4*6</b>




<7>



5 Small vertical board


4*40 self-tapping screws
<b>B4*2</b>





<8>



12 Base plate

4*40 self-tapping screws
<b>B4*6</b>




<9> Whole flip



26 Wooden legs

6*25 flat head screws
<b>E4*5</b>

Fix the 26 gauge wooden legs with 4 on the 12 gauge board




<10>




⑥ Pull plate

4*40 self-tapping screws
B4*5




<11>

(Insert K11 into the round hole)



⑳ back panel

breathable hole	small nails
K11*1	K20*18




Knock in the K20 with a tool hammer  
(You need to bring your own tool hammer)

<12>



25 Middle back panel

breathable hole	small nails
K11*1	K20*8




<13>



24 Backboard

breathable hole	small nails
K11*1	K20*18



Dear, for the sake of beauty, it is recommended to use tape to close the gap on the back panel until it is flush (you need to bring your own tape)

<14> Overall alignment



Insert KO on board No. 3-4. There are two upper and lower holes on the inside.  
The purpose is to make the shelf adjustable (the shelf can be placed diagonally to accommodate larger shoes)

<15>




14 Shelves




The small holes on the upper side of the door panel are filled with KO




Iron partition pin
K0*3



⑰ door panel



⑮ Left door panel

		
door hinge	Single hole door iron absorber	3.5*12 self-tapping
K2*3	L19*3	A1*9

The eye mark on the door panel

Fix 19 with A1

1. Align the KO above the door panel

Insert into the small holes under No. 7 and No. 10 plates



2. Insert K2 into the small hole on the number board first,

then align the guide hole on the door panel with the hole of

K2 and tighten it with A1 first. After the door panel is adjusted,

tighten everything

<17>

Insert KO. The function of KO is to prevent the drawer from falling

out when it is pulled out.



<18> Completed picture

