

# CC023 Installation Instruction

Please be sure to use a manual screwdriver and refrain from using an electric drill.



## 1. Product accessories and quantity

			
Eccentric wheel + eccentric rod	3.5*12 self-tapping screws	Long wooden handle	4*16 handle screw
D14x5 (spare plus 1)	A1 x 3 (spare plus 1)	J3*2	B8x5 (spare plus 1)
			
4*35 self-tapping screws	Single hole door iron absorber	iron shelf pin	Built-in door catch
B3 x 22 (spare plus 2)	L19*2	KOX 24 (spare plus 2)	L18*2
			
small nails	Spring spacer pin		screwdriver
K20 x 23 (spare plus 2)	L8*2		1

## Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

### 2. Installation steps of eccentric parts



Screw the eccentric rod to the board



Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole




Rotate 180° clockwise to lock  
the board left and right




### 3. Start the installation: Install the upper part

<1>

L18 on board No. 1 is on the upper left and facing forward




2. The side with more holes on No. 3 board is at the bottom and installed oppositely.



② Upper left panel


③ Upper right panel

Mount L18 on board No. 1 with the L18 magnet facing sideways.



① Cover





Circle the small hole on board No. 7 on the upper right



⑦ Door lower board


The upper part is installed


4*35 self-tapping screws
B3*4


#### 4. Installation of the lower part

<1> Screw D14 (eccentric rod) into the front non-penetrating holes on No. 8 board

Install L18 on the reverse side of No. 8 board with the L18-magnet facing the side.





(front)




(reverse side)

⑧ Connect the laminate

	
Eccentric rod	Built-in door catch
D14*4	L18*1

<2>

L18 on board No. 8 is on the upper left and facing forward



Circle the small holes on No. 4 and No. 5 plates at the top and in front.

(4)

(5)



⑧ Connect the laminate



④ Lower left side panel




⑤ Lower right panel



<3>

Circle the small hole on board No. 7 on the upper right



⑦ Door lower board






① skirting board

4*35 self-tapping screws
B3*4

5. The overall installation is as follows

<1> Flip the whole thing and connect the upper and lower parts




Eccentric wheel
D14x4

Knock in the K20 with a tool hammer




(You need to bring your own tool hammer)



Dear, for the sake of beauty, it is recommended to tape the gap on the back panel until it is flush (you need to bring your own tape)



② Large back panel



③ Small back panel



<3>

Straighten the whole



Plug KO into boards 2, 3, 4, and 5. There are two holes on the inside of the board, the upper and lower holes.

Only one KO needs to be installed.

The purpose is to make the shelf adjustable.



iron shelf pin

KO\*20

<4>

Place the movable layer board on the KO



⑥ Movable laminate





<5>

L8

KO



⑨ Small door panel



Use A1 to fix L19 at the guide hole on the door panel.



Insert L8 into the large hole in the door panel



Insert KO into the small hole on the door panel



① Door panel

			
3.5*12 self-tapping screws	Single hole door iron absorber	spring partition Pin iron partition pin	
A1*2	L19*2	L8*2	KO*2


1. Align the KO on the door panel with the small hole under No. 1 and No. 8 boards and insert it.



2. Press and hold L8 under the door panel and push it until it fits into the small hole on the No. 7 panel.



	
Long wooden handle	4*16 handle screw
J3*2	B8*4



Complete the picture

